
80.00 mm 80.00 mm

TEMPEST M20 GAMING SPEAKERS

INSTRUCTION MANUAL



- Volume up button
- Volume down button
- Power button
 Long press:
 open / shut down speaker
 Short press:
 change AUX / Bluetooth input
- 4 LED light
- 5 USB plug, connect to power
- 3.5mm AUX input plug
- Led light change Switch Change LED led light colors Open/shut down LED light

How to Use

- 2. Open the music.
- 3. Open the speaker (Long press " $\ensuremath{ \mbox{@}}$ " open / shut down speaker),
- 4. Press " 7 "open/shut down LED light
- 5. Short press " $\ensuremath{ \textcircled{3}}$ " to change mode "AUX" or "Bluetooth"
- 6. In AUX mode, The music come from the 3.5mm Audio cable.

 Short press "①" make volume up, Short press "②" make volume down.
- 7. In Bluetooth mode, you can make a pair with "TempestM20" by phone.

 Short press " 10" make volume up, Short press " 20" make volume down.

 Long press " 10" make next song,Long press " 20" make previous song
- 8. Short touch LED Switch " ", you can get the different lighting effects " 4".



MORE INFORMATION AT www.tempestofficial.com



80.00 mm 80.00 mm