
80.00 mm 80.00 mm




INSTRUCTION MANUAL



1. Computer connection mode


Tip: Two lines need to be connected at the same time to use, insert the computer back board, the sound quality will be better



2. Phone, tablet, MP3/MP4 connection mode

Tip: You must use 5V charging cap over 600mA (Above 1000mA is better)

3. Operating keyboard instructions



Reminder

- 1. Speaker power supply is DC 5V, audio input is 3.5mm universal audio interface.
- When the speakers are used and placed, should be placed in a cool and dry environment, not in humid places, not close to high temperature objects, when placed, please pay attention to anti fall.
- 3. This machine adopts DC 5V power supply, it is connected with USB thread head, and can not use too high or low voltage. This machine only supports 3.5mm universal audio interface as input, other audio input interface is not supported.
- 4. Please don't open the rear shell at will. If it needs repairing, please send it to our company or professional maintenance staff.

MORE INFORMATION AT www.tempestofficial.com



80.00 mm 80.00 mm