



Materiales	Metal in top cover, ABS in bottom cover
Keycaps	ABS double injection
Cable	1.8M Braided cable
Switch	Outemu, over 50000,000 lifetime
Dimension/Weight	440x132x43mm (LxHxW)/1950g
Battery capacity	2000mAh
Battery type	Lithium ion battery
Battery life	22h (Light on), 100h (Light off)

CONNECTION METHOD



Turn the button on the bottom to ON to enter into 2.4G mode, OFF for enter wired mode.



While enter the wireless mode, press Fn + R for more than 3s, the R key will flash green light, then input the 2.4 dongle. The led will off after connect successfully.

FN KEYS COMBINATION

Fn+Esc	Reset
Fn+F1	Screen brightness -
Fn+F2	Screen brightness +
Fn+F3	Multi-task window
Fn+F4	Program listing
Fn+F5	Backlight brightness -
Fn+F6	Backlight brightness +
Fn+F7	Previous
Fn+F8	Play/Pause
Fn+F9	Next
Fn+F10	Mute
Fn+F11	Volume -
Fn+F12	Volume +
Fn+WIN	Lock WIN

Fn+A	Win system
Fn+S	Mac system
Fn+TAB	Change led mode
Fn+Up arrow	Brightness speed +
Fn+Down arrow	Brightness speed -
Fn+Left arrow	Change led direction
Fn+Right arrow	Change led color
Fn+1/2/3	to enter customise backlight
Fn+D	enter into record mode.
Fn+X	Choose the key and color you want, then press Fn+D to save.
Fn key	will fast flash red light if low battery, remind you to charge your keyboard
Fn key	steady red light for 5s while charging.
Fn key	steady green light for 5s after the charging is finish.



Materiales	Metal en la cubierta superior, ABS en la cubierta inferior
Keycaps	Cable inyección doble ABS
Cable	1.8M Braided cable 1.8M
Interruptor	Outemu, más de 50.000.000 de vida
Dimensión/Peso	440x132x43mm (LxHxW)/1950g
Capacidad de la batería	2000mAh
Tipos de batería	Batería de iones de litio
Duración de la batería	22h (con encendido), 100h (con apagado)

MÉTODO DE CONEXIÓN



Gira el botón de la parte inferior a ON para entrar en el modo 2.4G, OFF para entrar en el modo con cable.



Al entrar en el modo inalámbrico, pulse Fn + R durante más de 3 segundos, la tecla R parpadeará en verde, luego introduzca el dongle 2.4. Si led se apagará después de conectar con éxito.

COMBINACIÓN DE TECLAS FN

Fn+Esc	Reiniciar
Fn+F1	Brillo de la pantalla -
Fn+F2	Brillo de la pantalla +
Fn+F3	Ventana multitarea
Fn+F4	Lista de programas
Fn+F5	Brillo de la luz de fondo -
Fn+F6	Brillo de la luz de fondo +
Fn+F7	Anteriormente
Fn+F8	Jugar/Pausa
Fn+F9	Siguiente
Fn+F10	Silencio
Fn+F11	Volumen -
Fn+F12	Volumen +
Fn+WIN	Cerradura WIN

Fn+A	Sistema Win
Fn+S	Sistema Mac
Fn+TAB	Cambiar el modo de los leds
Fn+Up arrow	Velocidad de brillo +
Fn+Down arrow	Velocidad de brillo -
Fn+Left arrow	Cambio de dirección de la guía
Fn+Right arrow	Cambiar el color del led
Fn+1/2/3	para entrar en la personalización de la luz de fondo
Fn+D	entra en el modo de grabación.
Fn+X	Elige la tecla y el color que desea, y pulse Fn+D para guardar.
La tecla FN	parpadeará rápidamente en rojo si la batería está baja, para recordarle que debe cargar el teclado.
La tecla FN	se ilumina en rojo fijo durante 5 segundos mientras se carga.
La tecla FN	se ilumina en verde durante 5 segundos después de la carga.